

6 Maintenance

For all work on the device, the general instructions in the chapter [Safety instructions](#) [> page 3] must be observed!

DANGER**Toxic, corrosive gas/condensate**

Sample gas/condensate may be hazardous to health.

- a) If necessary, ensure a safe gas/condensate discharge.
- b) Always disconnect the gas supply when performing maintenance or repairs.
- c) Protect yourself from toxic/corrosive gasses/condensate when performing maintenance. Wear appropriate protective equipment.



The base version of the cooler requires no special maintenance.

However, it may have different options depending on the configuration ordered. In this case the following routine maintenance is required:

Filter option: Check filter element (see chapter [Replacing the filter element \(option\)](#) [> page 21]).