

Table of Contents

1	Introduction	2
1.1	Intended Use	2
1.2	Type Plate	2
1.3	Scope of Delivery	2
1.4	Ordering instructions	3
1.5	Product Description	3
2	Safety instructions	4
2.1	Important advice	4
2.2	General hazard warnings	5
3	Transport and storage	6
4	Installation and connection	7
4.1	Installation site requirements	7
4.2	Installing the sampling tube (optional)	7
4.3	Installing the downstream filter (optional)	7
4.4	Insulation	7
4.5	Connecting the Gas Line	8
4.5.1	Connecting the Gas Line	8
4.5.2	Connecting the calibrating gas line (optional)	8
4.6	Electrical connections	9
4.6.1	Connection via Terminal Strip	9
4.6.2	Heated Extension (Optional)	9
5	Operation and Control	10
5.1	Basic function of the probe controller	10
5.1.1	Regulator Functions	10
5.1.2	Advanced Functions with Built-In Regulator for Heated Extension (Optional)	10
5.2	Use of menu functions	10
5.2.1	Menu Navigation Overview	11
5.2.2	Detailed description of the operational principle	12
5.3	Description of menu functions	12
5.3.1	Main Menu	12
5.3.2	Probe Controller Submenu [Display: Prob]	13
5.3.3	Regulator Submenu for Heated Extension [Display: Adon] (Optional)	13
6	Service	14
6.1	Maintaining the filter element	14
6.1.1	Replacing the downstream filter	15
6.1.2	Replacing the Outlet Filter with Micro-Fibreglass Filter Element	15
7	Service and repair	16
7.1	Troubleshooting	16
7.2	Spare Parts	17
8	Disposal	18
9	Appendices	19
9.1	Technical Data	19
9.2	Flow chart	19
9.3	Dimensions	20
9.4	Dimensions (ANSI flange)	21
9.5	Connection Diagram	22
9.6	User book (Please make copies)	23
10	Attached Documents	24