

# Sample gas probe GAS 222.35-U Ex1

In many applications gas analysis is the key for safe and efficient control of process flows, environmental protection and quality assurance. In extractive gas analysis the location of the gas sampling point is crucial for the reproducibility and accuracy of the analysis results.

The specific filter capacity, corrosion resistance and functional equipment requirements for the probe arise from the composition of the sample gas.

However, operating costs are also an important criterion in the selection, as the sampling points are frequently located at hard to access points in the system. Effective particle filter backwashing options and low maintenance characterise the extensive GAS probe series. Versions with Atex and IECEx approval

Unheated probe with upstream filter

The filter element can easily be removed by turning the handle 90°

For dust loads up to 200 g/m<sup>3</sup>, non-condensable gases

This probe is designed for use in explosive areas. Use in zone 1 and 21 and sampling from zone 0 and 20.



### **Technical Data**

### Gas Probe Technical Data

Ambient temperature without accessories							
Ambient temperature with accessories:	Component	Ambient temperature range					
	Compressed air valve:	-22 °F < T <sub>amb</sub> < 131 °F					
	Terminal box:	-4 °F < T <sub>amb</sub> < 131 °F					
Permissible gas inlet temperatures:	Outer zone temperature class	Permissible gas inlet temperature					
	Τ2	275 °F					
	Т3	275 °F					
	T4	266 °F					
Medium temperature (blowback):	Component	Medium temperature range					
	Compressed air valve:	14 °F to 176 °F					
Max. operating pressure	85 psia						
Max. flow rate:	16.66 lpm						
Material:	1.4571						
Parts in contact with media:	Seals: PTFE/graphite/1.4404 and see filter						
Probe marking, depending on the selected options and temperature class:	<b>for zone 0/1:</b> ATEX: 🖾 II 1G/2G Ex db <sup>1</sup> eb mb <sup>2</sup> IIC T4 Ga/Gb IECEx: Ex db <sup>1</sup> eb mb <sup>2</sup> IIC T4 Ga/Gb						
	<b>for zone 1:</b> ATEX: 🖾 II 2G Ex db¹ eb mb² IIC T4 Gb IECEx: Ex db¹ eb mb² IIC T4 Gb						
	for zone 0/21: ATEX: 🐼 II 1G/2D Ex db <sup>1</sup> eb mb <sup>2</sup> 11C T4 Ga Ex tb mb <sup>2</sup> 111C T130 °C Db IECEx: Ex db <sup>1</sup> eb mb <sup>2</sup> 11C T4 Ga Ex tb mb <sup>2</sup> 111C T130 °C Db						
	for zone 20/1: ATEX: 🐼 II 1D/2G Ex ta 111C T130 °C Da Ex db <sup>1</sup> eb mb <sup>2</sup> 11C T4 Gb IECEx: Ex ta 111C T130 °C Da Ex db <sup>1</sup> eb mb <sup>2</sup> 11C T4 Gb						
	<b>for zone 20/21:</b> ATEX: 🐼 II 1D/2D Ex ta/tb mb² IIIC 1 IECEx: Ex ta/tb mb² IIIC T130°C Da/D						
	<b>for zone 21:</b> ATEX: 🖾 II 2D Ex tb mb² IIIC T130°C Db IECEx: Ex tb mb² IIIC T130°C Db						
	<sup>1</sup> "db" only for GAS 222.11/30 versions with limit switch <sup>2</sup> "mb" only for versions with solenoid valve						
Applied standards:	IEC 60079-0 (Ed. 6.0); IEC 60079-7 (E EN 60079-0:2012+A11:2013; EN 6007						
IECEx certificate number:	IECEx IBE 17.0024X						
ATEX certificate number:	IBExU17ATEX1088X						

### **Ordering instructions**

The item number is a code for the configuration of your unit. Please use the following model key:

22235	Х	X	X	Х	Х	4	0	0	Х	X	X	XX	X	Product Characte	eristics		
														Terminal box			
	0													No			
	1													Yes			
														Flange			
		0	_											Flange DN65 PN6	5		
		0	2											Flange DN3"-150			
		Х	х											Other			
						Hazardous area											
				Outside													
				4										Zone 1 (Atex/IECE			
				7										Zone 21 (Atex/IEC	CEx)		
				9										none			
													Inside				
				3									Zone 0 (Atex/IECI				
				4									Zone 1 (Atex/IECE				
				6									Zone 20 (Atex/IEC				
				7									Zone 21 (Atex/IEC	CEx)			
				9									none				
					Temperature class (inside/outside)												
																Da/Gb or Db/Gb	
						4									T4/T130 °C	T130 °C/T4	T130 °C/T130 °C
														Calibration gas p	ort		
									0					No			
									1					6 mm			
								2					6 mm with check	valve			
									3					1/4"			
									4					1/4" with check va	alve		
														Pressure vessel *			
										0				No			
										1				Yes			
														Purge valve *			
											0		_	Ball valve			
											1			Solenoid valve 110	•	,	
											2			Solenoid valve 23			
											3			Solenoid valve 24	4 V (marked with	"mb")	
											9			none			

\* Blowback of explosive atmosphere prohibited.


## GAS 222.35-U Ex1

### Options

The base unit becomes functional by adding accessories suitable for the application. Please refer to accessory data sheet no. 461099 for information.

Please also refer to data sheet no. 461000 "GAS 222 Gas Probes" for a general description.

### Flow chart



### GAS 222.35-U Ex1

### Dimensions

